UNBOUND NOTES AND DRAWINGS
1898

1897

Cable Address "Edison, New York."

From the Laboratory
of
Thomas A. Edison.

Subject, Orange, N.J.,



April 1908


Meter
April 1998

Edison N. J. June 1-1898

Jno Kellogg-

all right go ahead with Manganin.

Have try how far magnetic lines from 4th pole pieces can be made to effect minor galvanometer needle with amperes varying from one to as far as you can go with battery or lamp bank across light circuit

Thos A. Edison -

Telephone Message

Jno Ott-

Have all testing & adjusting work in the Lab completed & Fine Calibrating, during holidays & be sure to work on the Meter dep't Testing the resistance and giving most data there shows current to fifty thousandths. The weight placed on the needle ~~to~~ depending from its middle ~~of~~ its balancing point to accomplish the desired result of lengthening or shortening the time of trip & the retarding action of the weight going up & are being exactly counteracted by the accelerating effect coming down and the net result will be the same wherever the weight is placed. Meters will have to be altered to suit some means of calibration. Will arrange all this with you & Charnal & Eaton.

Erratic action of meters just now

last night and I may hear out
during of interval Rest.

June 29. E. S. Bellogg.

Telephoned 6/24-98
to Smith

July 28/98

Kw Kellogg-

Crystals will not form with weak Current on Mercury Meter, better add resistance until it trips in couple of hours, what is changed or different about #6 Meter other than Carbonate Solution has in the guarded electrodes and excess of Cyanide

Edison-

Telephone message July 28th 1895

Received at 6.40 P.M.

Kellogg

You did not answer my enquiry as to what the difference is on Saturday between the Carbonate solution Nelson use & apply it & those also I sent you by last telegram That mercury removed probably not crystals if you added sometimes to bring it to 4 or 5 mil ampères if there is a yellow coat formo its due to want of nitric acid

Edison

July 25th

1	2	3	4	5	6	
4.058.00	2.44.00		458.00	3.15.00	456.30	6 00 – 17¼
11-58.00	8.03.00		6,48.00	8,453,30	614 00	6 10 – 17¼
4116-30	10.46.00		8,33.30	418,00	7,32.00	6 20 – 17¼
	1.17 30		10.14.30	9.12	8,49.30	6 30 – 17
	4,12,00		11,58.00	2-47-30	0,06 30	6 40 – 17
			140.00		11-24-30	6 50 – 17
	6-47-30		326,00		12.41,00	7 00 – 17
	9.12		5.23..		2.01.00	7 10 – 17
	11-33-30					7 20 – 17
	2-05.00		7.18.00		3.18.00	7 30 – 17
	4-45,00		9.02		11,35 00	7 40 – 17
			10-50.00		602 00	7 50 – 17
			12-2500		709-00	8 00 – 17
			2-00-00		6.24	8 10 – 15½
			3-36,00		9,43	8 20 – 18
					11.02-30	8 30 – 17½
					12.22.00	8 40 – 17½
					1-45-00	8 50 – 17¼
					2-5630	9 00 – 17½
					4-12,30	9 10 – 17¼
						9 20 – 17¼
						9 30 – 17¼
						9 40 – 17¼
						9 50 – 17¼
						10 00 – 17¼
						10 10 – 17¼
						10 20 – 17¼
						10 30 – 17¼
						10 40 – 17¼
						10 50 – 17¼
						11 00 – 15½
						11 10 – 18
						11 20 – 17¼
						11 30 – 17½
						11 40 – 17½
						11 50 – 17½



1	2	3	4	5	6	Remarks
1.44.30	5.40.00	6.00	~~1.00.00~~ 2.19.00	9.33.00 1.33.00 6.44	10.8.2 1.25.00 4.8.00	Cheque
396.5	75.5	5.82.5	893.0	315.5	9.16	
396.5	7570	42.0	894.5	316.5	576.0 5.81.0	Cheque
	9.15.00		10.35.0 3.49.00	1.47.00	11.00.00 1.16.00	

Kellog=

Use the suspended Mercury Electrodes - in 3 or 4 meters with Aluminum Beams -

get some Mercury from pump room, and put ~~enough for~~ ~~each~~ in ~~1~~ shallow dishes of which there are some in Room 11 - Treat with 10% Solution of Nitric acid for Couple hours, stirring well then wash acid all out. Then ~~Put~~ Divide it in several

portions, Each sufficient for one meter -

Then added to 1 portion 25% of its weight of ~~this~~ sheet zinc we used in meter, cut in thin strips - + let it dissolve in Mercury ~~overnight~~ it may not all dissolve But that doesn't matter =

Set three meters up with strong Sulphate of Zinc ~~solution~~ say 50% Sol =

Another portion used Cadmium in strips of Cadmium Sulphate -

Another portion use Silver + Strong Cyanide Silver in excess of Cyl Potassium —

Make up one meter with Nitrate Mercury & mercury alone = Fred'k. has the Nitrate Mercury Solution — Stohard to be filtered =

Make 6 shunts of the size given by Fred ott to be put in the Meter —
Make them of platinoid if that proves ael right —



give as much radiating surface as possible —
If the surface is insufficient. we might make 2 strips putting them 1/4 inch apart thus giving Ventilation —

Kellogg - Set up one of the regular Zinc Electrode meters with Sulphate of Zinc same as originally set up but so connected that the cells are not in series - the current is not reversed. Use only one shunt so that when lever goes to one side one cell is in - the other disconnected & when it goes to other side the 2nd cell is in - and the other out. Pass the current so it will plate off of the suspended electrode in both cells -



By this means the record will be made entirely by removing Zinc & we should get rid of the Hydrogen effect - also bad plating - as neither will interfere. If we use 20 milliampere 3 or 4 hours each day a Couple of oz of Zinc on each electrode would last 2 years or more -

Kellog -

It has occured to me that if we make a saturated solution of Cyanide of Silver & Cyanide of potassium - ~~(both saturated)~~ with smallest quantity of water - that the solution will no longer be able to get more dense at the bottom as it will be as dense as possible all over - You could get this by making a saturated solution of Potassium Cyanide & then add Silver Cyanide until it would take up no more - then add a very little water so as to

~~Take~~ dissolve some fresh potassium Cyanide so as to have an excess you might even leave some extra pieces of undissolved Cyanide in bottom of Cell—



A is a bar of iron 1 foot long one inch diameter covered with paper to insulate it & then wound with one layer of No 14 15 or 16 or 17 BWG cotton covered wire. The end turn is tied by a string to the last 3 turns — a key & storage battery gives 5 amperes

B is the same as A except the wire is finer The resistance of the wire of which there may be one or more layers is equal to the Mirror galvanometer Employed. of which I think we have one of 1/2 ohm or less —

Now place the 2 magnets parallel to each other 1 ft apart & take the throw of the galvanometer on ~~close~~ Opening the ~~press~~ battery

Circuit, raise the deflecting magnet so as to make it as sensitive as possible to the full Extent of the Scale = take several readings

Now move the Secondary magnet 2 feet away from the Galleon magnet & take another reading - & then proceed one foot at a time until the galvanometer no longer gives any throw

or indication of an inductive Current,

Now make a second magnet both for the Galleon & the galvanometer the Galleon magnet wound to give the same ampere Turns as A of the 1st Experiment. & the galvanometer wound over its Entire length to give the same Resistance as the galvanometer - but both magnets to be Two feet long each

Then place them one foot ~~apart~~ apart + take readings receeding from the battery magnet one foot at a time — until you can no longer get readings on the galvanometer — as the throw will be greater on the 2 foot magnet than the one foot when you take the 1st reading

you may have to move the galv magnet several feet away to get the first reading

Now continue experiments with magnets, 4 + 8 feet long =

If galvanometer room is not long enough put one magnet in galv room the other in one of the other 6th grs.

7

Freddy Ott will cut the
worm off for you + rig
up lathe to wind the chart
magnets, the largest may
have to be wound by hand
without the can get it in
lathe, be sure the wire
does not cross with the
core. If we have no one
[redacted]
with [redacted] you
[redacted]
much more use 5/8 or 3/4
or 1 1/4 - if none of these
Tell Donald in the

8

Clare room to send night
over to Newark + get
the right amount of
Norway or other soft
iron (Norway preferred)
Coz of Newark keeps it

Elmer



Mercuric Nitrate –

~~Concentrated solution~~

Get Merck 10.3

28 c oz –

Mercury –

in water with 3% of
Nitric acid, agitate it
with glass rod for 1/2 hour
then wash out Solution by
flushing under hydrant stream
the Mercury Use double distilled water
mercury thermometer

2 lbs absolutely pure stick Zinc - Listed in Catalogue at 1.50 per lb -

1/2 lb Chloride Zinc Mercks guaranteed reagent

1/2 lb Nickel & Ammonium Chloride

1/2 lb Nickel & Ammonium Sulphate -

4 oz Carbonate Zinc pure

Kellogg

I think the reason of the high resistance is due to the Resistance of the Column of Liquid itself No amount of silver surface will decrease the resistance, the only advantage Silver surface will give us is that the deposit per square inch will be slower & more uniform and less liable to exhaust Liquid of the Silver at any unit surface.

You can easily determine the specific Resistance of the Liquid by measuring the resistance every time you separate the Electrodes a certain distance apart, You should set up an extra cell with the new solution and get the variation of resistance by rule & face of Lamp-black to ascertain what & reason [illegible] much [illegible] sample dusk Electrodes perforated like you have one of the nickel & platina wire can be used to make determination also while you are at the Curves you might run Liquid down to 20 above Zero

or even lower to ascertain if the solution crystalizes - John Ott and he would give you a night nurse so I hope you have getting rewards =

Edna

Want 4 of the Ni sheets



platinum

bent to say 10/1000 platinum wire -

all the platinums are connected together + all the Nickel sheets are connected together -


3
Make these
long of
Nickel

If Phillips finds that one
jar of potatoes are not enough
make another out for another
jar —


1/8 thick Block Oxalo
Screen of Bottom
gauge in cent
mounted


1/8
Zinc
1/8
Hard Rubber
1/16 or 3/32
1/4 inch hole
1/4
1/8 holes
1/8 apart.
Rows 1/8 apart
Dam holes in Rubber